

USE THIS TABLE TO DETERMINE SIZE WINDOW NEEDED FOR NUMBER AND PRIMARY CONDUCTOR(S)

WINDOW DIAMETER		1/2"	3/4"	1"	1 1/2"	2"	2 1/2"	3"	3 1/2"	4"	5"	6"
INSULATION TYPE RHW	AWG MCM											
	14	3	6	10	25	41	58	90	121	155	—	—
	12	3	5	9	21	35	50	77	103	132	—	—
	10	2	4	7	18	29	41	64	86	110	—	—
	8	1	2	4	9	16	22	35	47	60	94	137
	6	1	1	2	6	11	15	24	32	41	64	93
	4	1	1	1	5	8	12	18	24	31	50	72
	3	1	1	1	4	7	10	16	22	38	44	63
	2	—	1	1	4	6	9	14	19	24	38	56
	1	—	1	1	3	5	7	11	14	18	29	42
	0	—	1	1	2	4	6	9	12	16	25	37
	00	—	—	1	1	3	5	8	11	14	22	32
	000	—	—	1	1	3	4	7	9	12	19	28
	0000	—	—	1	1	2	4	6	8	10	16	24
	250	—	—	—	1	1	3	5	6	8	13	19
	300	—	—	—	1	1	3	4	5	7	11	17
	350	—	—	—	1	1	2	4	5	6	10	15
	400	—	—	—	1	1	1	3	4	6	9	14
	500	—	—	—	1	1	1	3	4	5	8	11
	600	—	—	—	1	1	1	2	3	4	6	9
	700	—	—	—	1	1	1	1	3	3	6	8
	750	—	—	—	—	1	1	1	3	3	5	8