HIGH VOLTAGE DC TRANSDUCER

5 YEAR


WARRANTY

DESCRIPTION

The **DVTH** is an isolated high-voltage dc transducer with a proportional Zero to Full-Scale (F.S.) output. Packaging is a compact, easy-to-install, DIN rail-mount enclosure.

FEATURES

· High-Voltage dc measurement



- · Input, output and instrument power are electrically isolated
- · Wide ac/dc instrument power range
- · DIN rail-mount enclosure

MODEL SELECTION

MODEL	OUTPUT	POLARITY
DVTH-1500B	0 to ±1mAdc	Bidirectional
DVTH-1500D	0 to ±10Vdc	Bidirectional
DVTH-1500E	4-20mAdc	Unidirectional
DVTH-1500EM	4/12/20mAdc	Bidirectional
DVTH-1500X5	0 to ±5Vdc	Bidirectional

SPECIFICATIONS

INPUT

Voltage(Range)	0-±1500Vdc
Over-range (without damage)	0-±1800Vdc
Impedance	≥1.5MΩ
Frequency	dc
OUTPUT	
Scaling 0 to F.S. Input = 0 to F.S. C	output (See Table)
Loading 5V, 10V	≥2KΩ
4_{20mA} $4/12/20mA$	0-5000

4-2011A, 4/12/2	0IIIA0-50002
1mA	0-10ΚΩ
Response (10% to 90%)	100µs
INSTRUMENT POWER	9-28V, dc/50-400Hz, ≤3W

ACCURACY (setpoint, linearity, offset)...... ±0.25% F.S.

DIELECTRIC TEST

Input to Output/Instrument Power	. 4000Vdc
Instrument Power to Output	500Vdc

TEMPERATURE & ENVIRONMENTAL

Temperature

Operating Range		40°C to +85°C
Effect (-30°C	to +60°C)	±0.005%/°C
(-40°C	to +85°C)	±0.008%/°C
Relative Humidity)-95%, non-condensing

PHYSICAL

Mounts on standard 35mm "Top Hat" ra	il, per EN50052/EN60715
Termination Wire Size	
IP Rating	IP20
Weight.	0.35lbs.

OHIO SEMITRONICS, INC. 4242 REYNOLDS DRIVE * HILLIARD, ONIO 43020-1204 PHONE: (614) 777-1005 * FAX: (614) 777-4511 WWW.OHIOSEMITRONICS.COM * 1-800-537-6732




APPLICATIONS


- Shunt isolation
- · Solar (PV) String monitoring
- Data Center UPS Battery monitoring
- · Utility Storage Battery monitoring


DIMENSIONS

NOTES: 1. ALL DIMENSIONS ARE IN INCHES (mm)

2. TOLERANCE ±0.03 IN. (0.8mm)








Dwg# 0902-01050-B Rev -B

CONNECTION DIAGRAM



Dwg# 0902-01050-B Rev -B



MODEL DVT

INSTALLATION INSTRUCTIONS

- 1. Installation should be performed by qualified electricians only!
- 2. Make sure electrical service is disconnected before making any electrical connections.
- 3. Branch circuit protection is required to be provided in accordance with the National and Local codes of the inspection authority.
- 4. Route wires as required and secure to terminals per connection diagram on this sheet and on the unit.

OPERATING INSTRUCTIONS

- 1. This unit is intended for indoor use at altitudes up to 2000 meters.
- 2. Transient overvoltages according to Installation Category II (overvoltage category), pollution Degree 2.
- 3. The output signal is intended to be "Not accessible to the user." To prevent contact with live circuits, the transducer is required to be mounted in an enclosure that requires the use of a tool for access.
- 4. If cleaning of the exterior surface is necessary, de-energize all services of supply (both measuring and instrument power circuits) and brush with a soft brush or blow off with low-pressure air. Use appropriate eye protection. Not suitable for hose-down cleaning.
- 5. Maximum operating temperature range is -40°C to +85°C.

WARRANTY STATEMENT

Ohio Semitronics Inc. warrants this unit to be free of defects in material and workmanship for a period of five years from date of shipment. This unit must not be used in any manner other than as specified in this document.

OHIO SEMITRONICS, INC. 4242 REYNOLDS DRIVE * HILLIARD, OHIO * 43026-1264 PHONE: (614) 777-1005 * FAX: (614) 777-4511 WWW.OHIOSEMITRONICS.COM * 1-800-537-6732